



Egg Carton - Fire Starters



Double Boiler • Water in Bottom Boil • Use a Steel Can in the Top • Cutup Old Candle Wax



Collect Dryer Lint • Put in the Bottom of Egg Carton • Used Straw from Halloween



Pour in Candle Wax as it Liquifies • Use Pliers & Rubber Gloves
• As it Solidifies • Cut Short Pieces of String • Insert into the Egg
Shell Cavities • Soak String with Wax and Put Upright.

For more Imagineering ideas Visit LesLaMotte.com

